

2D Barcode Scanner

User's Manual



AG010
Start

Introduction

This user's manual is designed for 2D barcode scanner. For detailed usage manual information, please download the complete user manual from our website or obtain from our distributor.

Programming the Scanner

Restore Factory Setting



AB000
Restore Factory Settings

Scanning the following barcode can restore the scanner to the factory defaults.

Illumination



CA020
Off



CA010
Flashing Mode



V6.0



AG000
End



AG010
Start

Good Read Beep



CD010
*0N



CD000
Off



CD030
High



CD031
Middle



CD032
Low

Scan Mode



DC020
Continuous Mode



AG000
End



AG010
Start



DC010
Induction Mode



DM000
Low sensitivity



DM030
Higher sensitivity

Caps Lock



DM010
*Ordinary sensitivity



DM020
High sensitivity



JD040
*Original Data



AG000
End



AG010
Start



JD042
Lower care compulsive



JD041
Upper care compulsive

Terminal



DJ000
*Disable terminal character



DJ010
Enable terminal character



DK010
Terminal character Enter(0x0D)

RS-232 Interface

Data Bits



BD020
7Bits



AG000
End



AG010
Start



BD030
8Bits

Baud Rate



BA030
*9600



BA000
1200



BA020
4800



BA040
19200



BA050
38400



BA060
57600



AG000
End



AG010
Start



BA070
115200

Parity Check



BB000
None



BB010
Even parity



BB020
Odd parity

Stop Bits



BC000
1Bits



BC010
2Bits



AG000
End



AG010
Start

Global Settings



AB020
Enable all symbologies



AB010
Disable all symbologies



AB040
Enable 1D symbologies



AB030
Disable 1D symbologies



AB060
Enable 2D symbologies



AB050
Disable 2D symbologies



AG000
End