

Barcode Scanner User Manual



Introduction

This user manual is quick start manual. For detailed manual information, please download the complete user manual from our website or obtain it from our distributor.

System Setting



WFFD980
Reset (Return to factory default)

Communication Interface



W070901
USB-KBW



W070902
USB virtual serial



W070903
USB-POS



W100900
RS232 serial port



W100910
PS2-KBW

Serial Parameters



Baud Rate



WFFD9D0
1200



WFFD9D2
4800



WFFD9D3
9600 *



WFFD9D5
19200



WFFD9D6
38400





W010F01
Start



W010F01
Start



W010F01
Start



W010F01
Start

Parity Check



W062900
None *



W062904
Odd parity



W062906
Even parity

Data bits



W082900
7 Bits



W082908
8 Bits *

Keyboard mode

Keyboard case control



W381A00
Default *



W381A20
Uppercase



W381A30
Lowercase

Keyboard Language



WFF1900
USA *



WFF1907
French



WFF1919
Turkish 1



WFF191A
Turkish 2



WFF191B
English

Barcode Enable and Disable



WFFD981
Enable all Barcodes



WFFD982
Disable all Barcodes



W016100
Disable Code 128



W016101
Enable Code 128



W0FFD990
Restore Code128 default setting



W036203
Enable UCC/EAN-128



W036200
Disable UCC/EAN-128



W036300
Disable AIM128



W036302
Enable AIM128



W010F00
End



W010F00
End



W010F00
End



W010F00
End